

electric stroller

BRD-2168



Installation instructions

- ◆ Please read this manual carefully before use.
- ◆ It is not a means of transportation and cannot be driven on public transportation roads.
- ◆ This manual contains important information, please keep it properly for future reference.
- ◆ In order to improve products and quality. Without notice, we may change part of the structure, appearance, packaging, and assembly methods of the product. If there is any discrepancy between the manual and the actual product, please refer to the actual product. beg to be excused!

Pinghu Jujun Vehicle Industry Co.Ltd.

Introduction

1.About product.....	P2
2.Parts list.....	P3
3.Parts diagram.....	P4
4.Installation steps.....	P5-P7
5.How to operate this product.....	P8-P12
6.Charge.....	P13
7.Troubleshooting.....	P14
8.Maintenance.....	P15
9.Battery handling.....	P16

INTRODUCTION TO THIS PRODUCT

Thank you for choosing our product. We hope that your child's subsequent childhood life will be richer and more exciting because of it. Please read the instructions carefully before use and keep them properly.

Suitable age	3-6years old	Battery	12V4.5AH*1 12V7AH*1
Bearable weight	Below 30KG	Motor	Steering motor RS380DC12V RPM 5500*1 Drive motor RS390DC12V RPM 16000*2 or *4
Material	PP	Best operating temperature	Below 40℃
Product size	99X54X46		
Charge	Input: 100-240V 50-60HZ	Charging time	8-12 hours Maximum time limit: 20hours
	Output: 12V 700Ma/12V 1000mA	fuse	7A self-reset 10A self-reset

Warning!

For the safety of your child, please read the warnings and assembly and use instructions carefully, and please keep this instruction manual properly.

- Assembly is by adults. This product contains small parts, please keep children away during assembly.
- Please remove the protective device and packaging plastic bag before installation.

Parts list

Order	name	Picture	Quantity	Remark	Order	Name	Picture	Quantity	Remark
1	Body		1		2	Windshield		1	
3	Seat		1		4	Wheel		4	4 identical wheels
5	Wheel hub		4		6	Rear view mirror		1	Left&Right
7	Steering wheel		1		8	Charger		1	
9	Manual		1		10	Remote control		1	
11	M8 Wrench		2						

Parts diagram



Tips: Some parts need to be installed on both sides of the product.

Order	Name	Number	Order	Name	Number
1	Body	1	2	Windshield	1
3	Seat	1	4	Wheel	4
5	Wheel hub	4	6	rearview mirror	1
7	Steering wheel	1			

Tool requirements

- 

Screwdriver (bring your own)
- 

Pliers (bring your own)
- 

Hammer (bring your own)

Installation steps

- This product needs to be installed by an adult, please allow at least 40 minutes for installation. The tablets contain small parts and potentially dangerous sharp edges or points. Please keep children away from moving parts.
- Please confirm all included spare parts before installation, and do not throw them away until the installation is completed.
- Required installation tools: screwdriver (bring your own), pliers (bring your own), hammer (bring your own).

1. Install front and rear wheels



Turn the body over

1. First put an M10 spacer on the front axle, then put an M10 spacer on the front wheel and tighten it with an M8 lock nut. Take out the wheel cover and align it with the wheel buckle and press firmly until the installation is completed. .
2. Place the rear wheel on the rear axle, align it with the plum blossom on the motor and push it tightly, put on the M10 gasket, tighten it with the M8 anti-loosening nut, take out the wheel cover, align it with the buckle on the wheel and press it firmly until it is installed. Finish.

Note: The wheels are not divided into front, rear, left and right, and the installation steps for the left and right wheels are the same.




2. Install the steering wheel

First, connect the music plug-in to the steering wheel plug-in, then press and hold the quick-plug buttons on both sides, align the steering wheel with the plug-in on the car body, and press firmly until the installation is completed.

3. Install windshield and reflectors



1. Take out the windshield, align it with the buckle on the car body, and press down until the installation is complete.
2. Install the reflectors on both sides (as shown in the picture) and press down until the installation is completed.



4. Connect the power supply

Connect the power supply before installing the seat (as shown in the picture)

Note: Power supply
installation location

Do not connect upside down.



Battery safety warning!

Different models or new and old batteries cannot be mixed.

Non-rechargeable batteries cannot be recharged. Charging may only be done under adult supervision.

Please remove the rechargeable battery from the product before charging.


Please place the battery correctly according to the positive and negative poles.

Please remove exhausted batteries from the product promptly.

Be careful not to short circuit.

Dry batteries cannot be used.


5. Install the seat



1. There is a limiter on the rear side of the seat to press and secure the seat from top to bottom.
2. Fix it with 4X12 flat head screws on the left and right sides of the seat (as shown in the picture) until the installation is completed.

Note: The seat screws are pre-installed at the seat position of the body, you need to unscrew them first.

How to operate the product



2. 4G Remote Control Instructions

Step 1: Install two AA batteries into the remote control

Step 2: Turn off the main power switch on the car

Step 3: Press and hold the two keys next to the "S" key at the same time. Don't let go when moving forward ▲ and backward ▼. Make sure to hold it down at the same time.

When the indicator light flashes, turn on the power of the car. If the red indicator light stops flashing, the code matching is successful.

Button description: "S" speed adjustment key changes one speed each time it is pressed. One light is on for low speed, two lights are on for medium speed, and three lights are on for high speed;

“▲” Forward, “▼” backward, “◀” left, “▶” right.

"P" is the brake button. Press it once to keep the car in the braking state, and all red indicators will flash. Press it again to release the braking state.

This product is prioritized by the remote control (determined by the structure of the product): if the product is under remote control control, the foot switch will not work; if it is not under remote control control, the foot switch will work.

Warning!

To prevent injuries and personal safety incidents:

- Do not allow children to use this product alone. It must be used safely under adult supervision. If children are using this product, an adult must accompany them.
- Do not use this product on public transportation roads, near vehicles, slopes or swimming pools and other dangerous places.
- Please wear shoes when using this product.
- Please sit in the car and do not stand casually.
- Applicable age: 3-6 years old; Maximum weight: 30KG.
- Do not operate this product on crowded roads.

Before using this product, please make sure that the following steps have been completed:


- important! When using it for the first time, please charge it for 8-12 hours and no more than 20 hours. Charging should be done by adults.
- Please have an adult assemble this product according to the instructions in the installation section. Among them, the power supply and circuit parts have been assembled.
- Wherever screws are required, please tighten them tightly.

Safe usage rules

Please read the following safe usage rules to your children and their playmates to make sure they understand them correctly.

- This product does not have brakes, please wear a helmet and protective gear when using it.
- Always use under adult supervision.
- Make sure children use it in a safe place.
- Do not use this product on public transportation roads, near vehicles, lawns, slopes, or near swimming pools and other dangerous places.
- Please use the product on a flat surface, such as at home or in a park.
- Do not use this product in a dark environment. Children may put obstacles on it and cause unnecessary accidents. Make sure to use it during the day.
- Do not use on wet ground or on slopes exceeding 15°.
- Do not use this product outdoors on rainy or snowy days.
- When changing forward and backward, please confirm that the product is completely stationary.
- Please use the product within the age and weight requirements.
- It is prohibited to change the wiring or install other live equipment.
- Regularly check product wiring.
- To ensure the installation is safe for children, please perform a safety check on the product before each use.
- When the product is running, please do not let children get close to the product, especially the tires of the product.
- This product has an adjustable safety belt. Please tell your children how to use it correctly. Please fasten your seat belt every time you operate the product.

Operation steps (please make sure the power is on)



Important!

When changing direction and speed, please stop the product completely to avoid damaging the gearbox and motor.

1) Turn on the power

2) Forward△

Press the "Forward" button.

Depress the foot pedal.

The product will move forward accordingly.

3) Stop○

Release the pedal

4) Reverse▽

Press the "Back" button.

Depress the foot pedal.

The product will be withdrawn accordingly.




Manual remote control switch

1.The remote control is invalid in manual mode

2.Manual remote control mode is invalid

How to operate an MP3 player




- 1) USB card slot: Insert the USB terminal and connect the audio source to play the sound.
- 2) Music Bluetooth mode switching: Press the button to play music, press it again to play in Bluetooth mode, press it again to switch back to music mode.
- 3) Music switch button, click to switch to the next song.
- 4) The music volume is reduced.
- 5) Increase the music volume.

How to operate the steering wheel



Circuit diagram



Charging precautions

Charging must be done by an adult!

Warning!

- Prevent fire and electric shock
- Use the original rechargeable battery that comes with this car. Do not replace or modify the battery device of this product to avoid fire and explosion.
- Do not use the charging equipment of this product with other products to avoid overheating, fire and explosion.
- Never modify the circuit. Changing the circuit system can cause fire and explosion and will permanently damage this product.
- Never connect the power terminal directly to avoid fire or explosion.
- Never allow charging equipment to come into contact with any water or other liquids.
- Flammable gas will be produced during charging. Do not charge near overheated or flammable items. Please charge in a well-ventilated area.
- Please use the correct tools to remove the battery. Do not use metal wire to remove the battery to avoid fire.
- Please charge in a dry place.



Warning!

- Remove any overheated parts and wash your hands promptly when finished.
- Do not open the battery. There are lead and acidic substances inside, which may cause poisoning and corrosion.
- Never open the charger. Exposed wires may cause electric shock. The charging process can only be completed by adults.
- Please protect the battery. Dropping the battery may cause permanent damage, thus affecting the normal use of the product.
- Before charging, please carefully check whether the circuit and components are intact. If there is any damage, please stop charging.
- Do not use up the battery. Please charge it in time after each use. If not used for a long time, please charge it every month. Make sure to charge the product.
- Do not place the battery upside down.
- Please check whether the battery cover is properly closed. Children may be injured if the battery flies out.
- Use this product under adult supervision.
- To prevent children from falling and colliding, please be careful when using the product.

- The charging hole is under the seat.
- When charging, please turn off the power of this product.
- When using it for the first time, please charge it for 8-12 hours. To prevent the product from overheating, do not charge it for more than 20 hours.
- When the product's driving speed slows down, please charge it in time.
- Please charge it in time after each use. If it is not used for a long time, please charge it regularly every month. Charging time is controlled at 8-12 hours, no more than 20 hours.



Warning!

This product has a charging protection device: When the product is charging, all functions will be unavailable.

1. The charging hole is under the seat.
2. Connect the charging port and charging hole.
3. Plug in the socket and start charging.

Troubleshooting

Fault type: The car does not move.

Cause analysis: The battery power is too low.

Please charge it in time after each use. If the product is not used for a long time, please charge it regularly every month. Each charging time is controlled at 8-12 hours and cannot exceed 20 hours.

Cause analysis: The thermal fuse tripped.

The battery of this product contains a self-resetting fuse. When the product is overloaded or operated incorrectly, the self-resetting fuse will be cut off for 5-20 seconds, and then it can be used normally again. The self-resetting fuse is located under the seat (as shown in the picture)

To prevent the fuse from being cut, please refer to the following guidelines:


Do not overload, maximum load capacity: 30KG.

Do not use this product to pull objects.

Don't drive on slopes.

Be careful not to let the tires get stuck in obstacles, which will cause the tires to run at high speed and the engine to overheat. Do not use this product in hot weather, as it will cause the accessories to overheat.

Do not change the circuit yourself, as this may cause the wires to short-circuit.



Cause analysis: The tire screws are loose. When the screw is loose, the tire will not be able to run forward gear. Before each use, please carefully check whether the tire screws are tightened.

Cause analysis: The battery connection is loose.

Please carefully check whether the battery connections are loose before each use.

Cause analysis: The battery is dead.

Is the battery placed in the correct position? Is the battery old? Please replace the battery with a new one in time.

Cause analysis: The circuit system is necrotic.

If the product is soaked in water or sand, it will cause necrosis of the circuit system.

Please keep away from liquid items.

Cause analysis: Motor necrosis.

Repairs are required by professionals.

Failure type: The battery cannot be charged.

Cause analysis: The battery connection is loose.

Please check carefully whether the battery connections are loose before use.

Cause analysis: The charger is not plugged in.

Please check carefully whether the socket is properly plugged in and powered on before use.

Cause analysis: The charger is not functioning properly.

Does the charger get hot when charging? If not, it means the charger is damaged, please replace it with a new one in time.

Troubleshooting

Type of fault: short cruising range.

Cause analysis: The battery power is too low.

There is not enough power in the battery. Please charge it in time after each use, or charge it regularly every month. Each charging time is controlled at 8-12 hours and cannot exceed 20 hours.

Cause analysis: Battery aging.

Depending on the frequency of use, batteries age to varying degrees and at different rates. When you find that the battery is aging, please replace it with a new one in time.

Type of fault: There is a sound when charging.

It's just normal.

Type of fault: heating during charging.

It's just normal.

Maintenance

·After normal use of this product, adults should regularly check the main components of the vehicle such as the battery, charger, wires, casing, switches and other components. The fastening parts must be checked to see if they are loose. In case of potential hazards, use should be stopped immediately until repaired.

·Please confirm that the plastic accessories are not cracked or damaged.

·After using for a period of time, please lubricate the vehicle with lubricating oil to prevent rust.

·Please store the product indoors. If you encounter humid weather, please use a tarpaulin to cover the product. ·Park the car away from high temperatures, as plastic parts are easily melted by overheating.

·Please charge in time after each use. If it is not used for a long time, charge the product regularly every month. The charging process is completed by adults.

·Do not use soap and water to clean the vehicle. Water will damage the motor battery and cause a short circuit in the circuit system.

·To clean the vehicle, you can wipe it with a dry cloth, or you can use non-wax furniture polish instead of a soft cloth to wipe the plastic parts to achieve a smooth surface effect.

·Do not use it in dangerous areas such as public transportation roads, slopes, gravel roads, etc. to avoid damage to the motor and circuit system.

·When not in use, please turn off the power switch. When not in use for a long time, please unplug the battery connector.

Battery Handling

Battery Handling



- The battery can be recycled and cannot be discarded at will.
- Do not discard the battery near a fire source, as it may cause explosion and leakage.
- Do not dispose of batteries with household waste. It is strictly prohibited by law to incinerate batteries with household waste.
- Put the used battery into the designated trash can or hand it over to professional staff.
- Please consult the relevant agencies for reasonable disposal methods before disposing of the battery yourself.
- Please charge this product before using it. The charging process must be completed by an adult.
- Please charge within the specified voltage requirement range. No other operations are allowed on the product while charging.
- Charging can only be done under adult supervision.
- Regularly check the sockets, lines, charging casing and other spare parts. If any damage is found, please stop using it.
- Open the battery cover on the remote control and insert two AA batteries according to the correct positive and negative polarities. (Please follow the above steps to have an adult replace the battery).
- Please check whether the positive and negative polarities of all batteries are correct.
- Non-rechargeable batteries cannot be charged. Please remove these batteries from the product promptly after use. New and old batteries or batteries of different types cannot be mixed together.
- Please check the condition of the battery regularly. If any damage is found, please stop using it until repairs are completed.

Pinghu Jujun Vehicle Industry Co., Ltd.

Address: 4th Floor, Building 3, No. 183, Tongche Road, Xincang Town, Pinghu City, Jiaxing City, Zhejiang Province

Tel: 0573-85715158

Fax: 0573-85715158

The company passed ISO 9001:2015 quality management system certification
Implement national standards;

GB 6675.1-2014 "Toy Safety Part 1: Basic Specifications"

GB 6675.2-2014 "Toy Safety Part 2: Mechanical and Physical Properties"

GB 6675.3-2014 "Toy Safety Part 3: Flammability"

GB 6675.4-2014 "Toy Safety Part 4: Migration of Specific Elements"

GB 19865-2005 "Safety of Electric Toys"