


Lamborghini Sián FKP 37

Electric Ride On

QLS-6988



Installation and Operation Instructions

Simulation car model

System driven by remote control

Forward, backward and steering operations by remote control

Forward, backward and steering operations by manual

Built-in music, external device music playback

Steering wheel's music function

Volume adjustment function

Power display

Maximum weight: 50KGS



IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

ASSEMBLY INSTRUCTION

 A x 1 Body	 B x 2 Front Wheel	 C x 2 Rear Wheel
 D x 4 Wheel cover	 E x 1 Steering wheel	 F x 1 Windshield
 G x 1 Chair	 H x 2 Rearview mirror	 I x 2 Seat backrest
 J x 1 Remote control	 K x 1 Charger	 L x 2 wrench

Product Specifications:

Battery: 12V10AH

Drive Motor: 12V550*4(12000RPM)

Steering Motor: 12V390*1(8000RPM)

Suitable age: 37-95months

Maximum weight: 50kg

Car Size: 140*81*47cm

Speed: 3-5km/h

Hours of Use: Using 1-2 hours after Charging 8-10 hours


Charger: Input: 100V-240V 50/60HZ

Output: 12V1A

Remote Control Battery : AAA1.5V*2(not provided)



Function



Function indication

1. Start/Stop
2. Previous/Next
3. Remaining power display
4. Volume increase/decrease
5. Gear display
6. Gear lever
7. Play/Pause
8. Random Play
9. MP3 interface
10. USB interface
11. Light button
12. Swing mode
13. Charger interface
14. Driving mode
15. Multi function switching
16. Music button

Remote Control Function and Instructions

Do not switch between forward and backward during the operation of the toy car, as it may cause damage to the gearbox and motor.

The product has been matched code before leaving the factory and can be used once the battery is installed. Only the child's guardian can use the remote control.

The product is operated mainly by remote control.

If the remote control connection fails, please refer to the following steps to match the code:

Hold down "Code" key for 3 seconds start match code, The first LED flicker; Turn on the car's power now, the first LED lit up, match code Success.

The remote control enters a silent state after 10 seconds of stopping use, and can be awakened by pressing any button.


Keys caption £ "△" Forward, "▽" Back, "◁" Left, "▷" Right, "S" Speed, "P" Brake.

Press "S" key set up speed , 1 led lit up is low speed£

2 leds lit up is medium speed£ 3 leds lit up is high speed;

When reversing, it only at low speed.

Press "P" key to hold the brake, All LED flicker.



Battery Operating Specifications:

Never mix new and old batteries, or different kinds of batteries.

Never mistake positive and negative electrode of battery, or short circuit will happen.

Non-rechargeable batteries are not to be recharged.

Install batteries in a right polarity.

Only adults can recharge or change batteries.

Never make power port' s short circuit happen.


Recharge the battery only when it is taken out of the toy car.

Take exhausted battery out of the toy car and keep it out of Children's reach.

Remove battery screws with a screwdriver, open battery cap as the arrow signals, and in the 2.4G remote control model install two AAA 1.5V batteries in a right polarity.


1. Install the front wheels

First, remove the nut and gasket from the front axle, then install the wheel, gasket and nut onto the front axle in turn, tighten the nut with a wrench, and finally install the wheel cover on the wheel. Install the front wheel on the other side in the same way.



2. Install the rear wheels

First, remove the nut, gasket and cardboard tube from the rear axle, then install the wheel, gasket and nut onto the rear axle in turn, install the rear wheel on the other side in the same way, tighten the nuts with 2 wrenchs, and finally install the wheel cover onto the wheel.



3. Install the steering wheel

First connect the steering wheel cable to the instrument panel, then plug the cable into the cable hole, and finally align the steering wheel with the connector.



4. Install the windshield


Align the windshield to the body position, and fix the clip to the hole position.



5. Install the rear view mirrors


Distinguish left mirror from the right one.

Then insert the mirrors into the hole site on the door.



6. Connect the power cord

Find the power cord interface and connect them, turn on the power switch to test if it is powered on.



7. Install the seats

Remove the four screws from the vehicle body, install the seat onto the vehicle body as shown in the diagram, and use a screwdriver to lock the two flat head screws onto the seat; Install the two backrests onto the vehicle body as shown in the diagram, paying attention to distinguishing the left and right sides, and use a screwdriver to lock the screws to secure the backrests.





WARNING

Warning: The toy must be assembled by an adult. In unassembled state contain potentially hazardous sharp points, sharp edges and small part, so please keep out of baby's reach.

Warning: Not to be used in traffic.

Warning: Only adults can install parts and adjust the car, and keep moving parts out of children's reach. Children can use the product only in the company of adults, and the adult cannot leave during the process.

Warning: Do not allow children to stand or play on the pedal (or in vehicle).

Warning: Only adults can charge the battery, and the product must be charged before the first use.

Warning: Keep such package materials as plastic bags out of children, or they will suffocate or kill children.

Warning: Never use parts provided by non-manufacturers. Never let children play with the charger. The number of connected power by the product can never be over the recommended number.

Warning: Toys used by children outside of private places may be potentially dangerous.

Warning: Only use the battery specified by the manufacturer. Only use the charger specified by the manufacturer.

Notice of use

Never use the product in such dangerous zones as streets, roads, slopes or drains.

Never change the circuit and additional electric devices.

Never pour water or other liquid into the car, keep the product out of the fire, otherwise the car will be damaged.

Only two children can use the product, and its weight cannot exceed 50KGS.

Turn off the power when not in use and unplug the power cord when not using it for a long time. Since the product is equipped with a battery charger, please check whether the wire plug housing and other parts are damaged, and repair the damaged parts.

Before assembling, screws and pins are dangerous sharp points.

Charging Notice

Charge the battery before the first use, otherwise the battery will be permanently damaged.

When charging, insert the DC plug into the charging hole and the charger plug into the power socket.

Do not use this product during charging.

The product can be used for one hour after being fully charged. The charging time is 8-10 hours, and the charging time cannot exceed 18 hours.

It is normal for the charger and battery temperature to rise (below 60 degrees).

Do not let the water contact the charging interface, or a short circuit may occur.

The charger provided with the product must be used, otherwise the charger and battery will be damaged, and even short circuit may occur.


Please charge the product when it is not used for a long time.

Charging steps are as follows:

Step 1: Find the charge hole on the central control pedal.

Step 2: Connect the charger cord to the charging point.

Step 3: Connect the charger to the power socket.



Trouble Clearing

Type	Analysis	Solutions
The car can not get started.	Low battery voltage; Protection of electric devices; Failure to press the switch button correctly; Falling of power connector; Battery breakdown; Damage of electric devices; Generator breakdown.	Charge battery fully; Use the car a few minutes later; Use the car according to instructions; Install the connector again; Change battery; Change electric devices; Change generator.
The battery can not be charged.	Falling of battery connector; No charging for the charger; Charger breakdown.	Install the connector again; Plug the charger again; Change the charger.
The car has a short range.	Not full charging of battery; Much-used battery.	Charge fully the battery again; Change the battery.
There appear slight noise and heat of the car in charging.	Chemical reactions.	Normal reactions.
The car has a slow speed.	Much-used battery; No electricity for battery; Overload; Uneven driving surface.	Change the battery; Charge fully the battery again; Reduce the load below 25 kilograms; Drive on uneven surface.

Maintenance and Service

After a period of use, parents should lubricate iron castings with lube, otherwise those castings will get rusted; they should keep the product out of fire and lay it flat in dark places; they should put the product inside the house or cover it with one water-proof cloth in wet weather.

Parents should keep the product out of such hot objects as stove and heater, otherwise its plastic parts may be thawed.

Parents should clean car surface with dry cloth, or clean plastic parts with non-waxy furniture polish; they shouldn't clean plastic parts with chemical solutions or clean the car with water; children cannot drive the car in wet or rainy weather, otherwise the car's circuit system will be damaged.

When not using or laying the product, parents should cut off car power, take out the battery. Parents shouldn't change product structure and circuit system, and should have the product checked and fixed by professionals or under the guidance of professionals.

The "Lamborghini" and "Lamborghini Bull and Shield" trademarks, copyrights, designs and models are used under license from Automobili Lamborghini S.p.A, Italy.

Licensed manufacturer: Pinghu Qileshi Baby Carrier Co., Ltd