


**DEALERS MUST TRANSLATE THEIR OWN LANGUAGE OF
MANUAL INSTRUCTIONS BELOW FOR YOUR MARKET
PLEASE READ THE INSTRUCTIONS
CAREFULLY BEFORE USE**



Styles and colors may vary

**Keep the package away from children and dispose of
properly before use**

1.Specification:

Motor	2 *45W	4 *45W
Battery	12V7AH*1	12V7AH*1
Charger	12V1000MA	12V1000MA
Speed	3.5-5km/hr	3.5-5km/hr

Suitable age : 37-96 months

Load Capacity: Under 30KGS

Size of car: 97×70×51CM

Power way: Charging type

Charge time : 8-12 hours

2.Packing list:

Number	Name	Quantity
1	wind shield	1
2	Rear windshield	1
3	steering wheel	1
4	Wheel	4
5	wheel hub	4
6	wheel trim part	4
7	steering lever connect part	1
8	charger	1
9	Spanner	1
A	Ø12 gasket	4-6
B	M10 nut	4-5
C	M6×25screw	1
D	M6 Spring gasket	1
E	M6 nut with gasket	1
F	Ø4×10 screw	11-13

- Make sure the plastic parts of the vehicle are not cracked or broken.
- Occasionally use a lightweight oil to lubricate moving parts such as wheels.
- Park the vehicle indoors or cover it with a tarp to protect it from wet weather.
- Keep the vehicle away from sources of heat, such as stoves and heaters. Plastic parts may melt.
- Recharge the battery after each use. Only an adult can handle the battery. Recharge the battery at least once a month when the vehicle Raider is not being used.
- Do not wash the vehicle with a hose. Do not wash the vehicle with soap and water. Do not drive the vehicle in rainy or snowy weather. Water will damage the motor, electric system and battery.
- Clean the vehicle with a soft, dry cloth. To restore shine to plastic parts, use a non-wax furniture polish. Do not use car wax. Do not use abrasive cleaners.
- Do not drive the vehicle in loose dirt, sand or fine gravel which could damage moving parts, motors or the electric system.
- When not using, all the electrical source should be turn off. Turn off the power switch and disconnect the battery connection.


Vehicle needs a push to go forward	Poor contact of wires or connectors	Check that the battery connectors are firmly plugged into each other. If wires are loose around the motor, contact your distributor please.
	“Dead Spot” on motor	A dead spot means the electric power is not being delivered to the terminal connection and the vehicle needs repair. Contact your distributor please.
Loud grinding or clicking noises coming from motor or gear box	Motor or gears are damaged	Contact your distributor please.
Battery with not recharge	Battery connector adapter connector is loose	Check that the battery connectors are firmly plugged into each other.
	Charger not plugged in	Check that the battery charge is plugged into a working wall outlet.
	Charger is not working	Contact your distributor please.
Charger feels warm when recharging	This is normal and not a cause for concern	

Completely read through this manual and the troubleshooting guide table before calling. If you still need help resolving the problem **Contact your distributor please.**

9.Maintaining

- It is parents’ responsibility to check main parts of the toy before using, Must regularly examine for potential hazard, such as the battery, charge, cable or cord, plug, screws are fastening enclosure of other parts and that in the event of such damage, the toy must not be until that damage had been properly removed.

3. Parts Diagram



WARNING!

FOR THE SAFETY OF YOUR CHILDREN , PLEASE READ ALL WARNINGS AND ASSEMBLY/USE INSTRUCTIONS.KEEP THIS GUIDE FOR FUTURE REFERENCE.

- ADULT ASSEMBLY REQUIRED. The product contains small parts, which are for adult assembly only. Keep children away when assembling.
- Always remove protective material and poly bags and dispose before assembly.

Assembly tools required:




Screwdriver
(not included)



Spanner
(included)

4.Operation Instruction:

(A) Install the bottom of Front ,back baffle and wheels (4 Motors)



- 1) Install the bottom of front baffle with Ø4×10 screw *2 ,fix it to the front main body of the car.
- 2) Fix the rear baffle to the back of car body with Ø4×10 screw *3
- 3) Fit the four wheels into the front and rear shafts to match the drive gear box
- 4) Put the Wheel caps onto the wheels
- 5) Put Ø12 gasket to the axle
- 6) Fixed the M10 nut to the axle with Spanner
- 7) Put the wheel trim part to the 4 wheels

NOTE:

When install the car with 2 motors, choose the wheel without the trim part and put them on front axle with Ø12 gasket. Then install according 2-6 steps
In order to prevent the wheel from shrinking, the user will decide whether to increase the gasket to adjust.

illegal in most areas to incinerate lead acid batteries or dispose of them in landfills. Take it to a federal or state-approved lead acid battery recycler, such as local automotive battery retailer.

Do not throw the battery away with your regular household waste!

- 7. Replace the battery and reconnect the connectors.
- 8. Replace the metal battery bracket.
- 9. Replace the seat.

8.Troubleshooting Guide

Problem	Possible Cause	Solution
Vehicle dose not run	Battery low on power	Recharge battery
	Fuse has broken	Replace,see<Fuse>
	Battery connector or wires are loose	Check that battery connectors are firmly plugged into each other. If wires are loose around the motor contact your distributor please
	Battery is dead	Replace battery , contact your distributor please
	Electrical system is damaged	Contact your distributor please
	Motor is damaged	Contact your distributor please
Vehicle dose not run very long	Batter is under charged	Check that the battery connectors are firmly plugged into each other when recharging
	Battery is old	Replace battery, contact your distributor please.
Vehicle runs sluggishly	Battery low on power	Recharge battery, contact your distributor please.
	Battery is old	Recharge battery, contact your distributor please.
	Vehicle is overload	Reduce weight on vehicle. Maximum user weight is 30 kgs.
	Vehicle is being used in harsh conditions	Avoid using vehicle in harsh conditions, see<safety>

seat or behind the body of the car. Replace and restart.

To avoid losing power , follow these guidelines:

- Do not overload the vehicle.
- Do not tow anything behind the vehicle.
- Do not drive up steep slopes.
- Do not drive into fixed objects, which may cause the wheels to spin, causing the motor to overheat.
- Do not drive in very hot weather, components may overheat.
- Do not allow water or other liquid to come in contact with the battery or other electric components.
- Do not tamper with the electric system. Doing so may create a short , causing the fuse to trip.


Battery Replacement and Disposal

The battery will eventually lose the ability to hold a charge . Depending on the amount of use , and varying conditions, the battery should operate for one to three years. Follow these steps to replace and dispose the battery:

1. Remove the car seat .
2. Disconnect the battery connectors.
3. Remove the metal battery bracket.
4. Remove the battery cover
5. Carefully lift the battery
 - Depending on the condition of the battery (i.e.: leakage) you may want to wear protective gloves before removal.
 - Do not lift the battery by its connectors or cables
6. Place the dead battery in a plastic bag.

Important! Recycle the dead battery responsibly. The battery contains lead (electrolyte) and must be disposed of properly and legally. It is


(B) Install the Front ,back baffle (4 Motors)



1. Install the front baffle with $\varnothing 4 \times 10$ screw *3 , fix it to the front main body of the car.

2. Fix the rear baffle to the back of car body with $\varnothing 4 \times 10$ screw *2

C: Install the steering wheel



1. Insert the steering wheel into the plastic part of the front of the car and through the iron support
2. Insert the bottom of steering lever connect part to the steering bracket slot
3. Insert steering wheel lever into the steering connecting rod slot and align the steering wheel to the steering connector hole
4. Put the M6*25 screw into the steering lever connect part . Fasten M6 Spring gasket into M6*25 screw. Make M6 nut with gasket into M6*25 screw tightly.



In order to prevent the steering wheel from being used for a long time, the utility model is easy to cause the screw to fall off and the steering wheel of the screw not to be screwed, and the use of the steering wheel is inconvenient. Please make screws more tightly. so that the parts fit together tightly

NEVER pick up the battery by the wires or charger. Damage can occur to the battery and may cause a fire. Pick up the battery by the case **ONLY**.

- Charge the battery in a dry area **ONLY**.

- Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. **Wash hands after handling.**
 - Do not open the battery. Battery contains lead acid and other materials that are toxic and corrosive.
 - Do not open the charger. Exposed wiring and circuitry inside case electric shock.. Only adults may handle or charge the batter. NEVER allow child to handle or charge the battery. Battery is heavy and contains lead acid (electrolyte).
 - Do not drop the battery. Permanent damage to the battery could occur or cause serious injury.
 - Before charging the battery, check for wear or damage to the battery, charger, its supply cord and the connectors. **DO NOT** charge the battery if any damage to parts has occurred.
 - Do not allow the battery to drain completely. Recharge the battery after each use or once a month if not used regularly.
 - Do not charge battery upside down.
 - Always secure the battery with bracket, Battery can fall out and injure a child if vehicle tips over.
-
- The **POWER SWITCH** must be turned in **OFF** position when charging.
 - Before the first use, you should charge the battery for 4-6 hours. Do not recharge the battery for more than 10 hours to avoid overheating the charger.
 - When the vehicle begins to run slowly, recharge the battery.
 - After each use or once a month minimum recharge times as 8 to 12 hours, less than 20 hours at most.

7.Battery Replacement &Fuse

If the fuse is broken, there has a spare fuse in the fuse box under the

5. Safety

WARNING!

PREVENT INJURIES AND DEATHS:

- **NEVER LEAVE CHILD UNATTENDED. DIRECT ADULT SUPERVISION REQUIRED.** Always keep child in view when child is in vehicle.
- This toy should be used with caution since skill is required to avoid falls & collisions causing injury to the user or third parties.
- Protective equipment should be worn.
- Never use in roadways, near cars, on or near steep inclines or steps, swimming pools or other bodies of water.
- Always wear shoes.
- Always sit on the seat.
- Not to be used in traffic.
- This toy is unsuitable for children under 37 months due to its maximum speed; Maximum user weight is 30 kgs.
- This toy has no brake.

Rules for Safe Riding


- Keep Children within safe riding areas:

Never use in roadway, near motor vehicles, on lawn space, on or near steep inclines or steps swimming pools or other bodies of water;

Use the toy only on flat surfaces. Such as inside your house, garden or playground

- Never use in the dark. A child could encounter unexpected obstacles and have an accident. Operate the vehicles only in the daytime or well-lit area.
- It is prohibited to change the circuit or add other electric parts.
- Inspect wires and connections of the vehicle periodically
- Do not let any child touch the wheels or be near them when the car is moving.


D. Power Connecting



1. Open the seat and connect the battery wires

Red to red ,Black to black


E: Function introduction



1. Pedal: Press , the car will move when the power on
2. Power Button: Long press 3 seconds, Turn the vehicle on and off. Long press 1 second, the music stop, press again, music on .
3. Power display: Clearly see the battery power, in order to charger in time
4. Forward button: Press it , go forward
5. Backward button: Press it , go backward
6. Speed button: Press it ,choice high speed or low speed
7. Bluetooth speaker button: Press it , connect your phone and play the music
8. FM: Radio
9. Music Button: Play music
10. Light button : Turn on or off the light
11. Next song: Switch songs, and long press will increase volume
12. Last song: Switch songs, and long press will decrease volume
13. USB solt
14. Socket : Charge
15. MP3 solt

F: Charging

ONLY AN ADULT CAN CHARGE AND RECHARGE THE BATTERY!



1.Charger the car as picture

WARNING!

● **PREVENT FIRE AND ELECTRIC SHOCK:**

- Use the only rechargeable battery and charger supplied with your vehicle. NEVER substitute the battery or charger with another brand. Using another battery or charger my cause a fire or explosion.
- Do not use the battery or charger for any other product. Overheating, fire or explosion could occur.
- NEVER modify the electric circuit system.. Tampering with the electric system may cause a shock, fire or explosion or my permanently damage the system.
- Do not allow direct contact between battery terminals. Fire or explosion can occur.
- Do not allow any type of liquid on the batter or its components.
- Explosive gasses are created during charging. Do not charge near or flammable materials. Charge the battery in a well-ventilated area ONLY.