

Please read the manual before using the product. The manual and carton contain important information, please keep them properly for later references. If failure to following the instruction in the manual, it might be dangerous for your child.

In order to improve the product and quality, we may change the parts of structure, appearance, packing method, assembly method and function of the product without any notice. When there is any difference between the manual and the product, please subject to the actual product. We are sorry for any inconvenience.



Hollicy

The assembly manual of
battery operated car

Model: SX2028

Executive standard:

EN71-1

EN71-2

EN71-3








EN62115



WARNING:

Products should be assembled by an adult. Protective equipment should be worn. Not to be used in traffic. Not suitable for children under 3 years. Choking hazard- small parts. In unassembled state, contains potentially hazardous small parts. Please keep out of the reach of small children. Pay attention to the potential hazards of using the toy in areas other than private grounds.

PARTS LIST

PARTS NAME	PICTURE	QTY	PARTS NAME	PICTURE	QTY
Car body		1PC	Windshield		1PC
Steering wheel		1PC	Seat		1PC
Mirror		2PCS	Spoiler		1PC
Wheel		4PCS	Wheel cover		4PCS
MP3 (optional)		1PC	Motor		2PCS
MP4 (optional)		1PC	MP3 (optional)		1PC
Charger		1PC	Remote control		1PC
Manual		1PC			

Disclaimer:

The pictures in this instruction are for assembly reference only.
Please refer to the actual product.

WARNING:

This product is not the vehicle for transportation, it should be used under adult guidance. Parents should ensure that children have taken the safety measures before use.

The toy should be used with caution since skill is required to avoid falls or collisions causing injury to the user or third parties.

PRODUCT SPECIFICATIONS

Battery	12V7AH / 12V10AH / 12V12AH / 12V14AH 12V7AH*2 12V9AH*2
Main material	PP
Suitable age	37-95 Months
weight limit for the car	60kg
Product size	1350X807X515mm
Speed	3-8 KM/H (10-15KM/H for drift functon)
Runtime	1-2 hours after charging for 8-12 hours, based on ride on conditions
Charger	Input AC 110 -220V Output DC 12V500 -1000mA Input AC 110 -220V Output DC 24V500 -1000mA
Fuse	Auto-reset fuse

Stroller function


Pull the handle and caster wheels out if needed. When not needed, push them back to save space.

Removable battery box function (optional)

The battery box in the rear trunk is removable, which can be taken out for charging independently. It is convenient and easy to handle. (Specific operation refers to the power diagram.)

Adjustable seat Function

Pulling the handle under the seat, the seat can be adjusted to front and back.



Assembly instruction


Car assembling should be done by the adults.

Take care of small parts. To avoid choking hazard, keep children away while assembling. Children under 36 months are prohibited to use.

Please count all the parts carefully before assembling and dispose the plastic bag properly. To avoid choking hazard, children are not allowed to play with the bag.


1. Battery connection

Connect two red plugs under the seat to connect the power.




2. Front wheel assembly

Turn over the car body, keep the car upside down, use the prepared sleeve tool to remove the nut and washer, then attach the front wheel to the front axle, insert the washer and fix the nut with sleeve tool. Assemble the wheel cover.



Drift front wheel assembly (optional)

Turn over the car body, keep the car upside down, use the prepared sleeve tool to remove the nut and 10mm washer, no need to remove the 12mm washer, then attach the front wheel to the front axle, insert the 10mm washer and fix the nut with sleeve tool. Assemble the wheel cover.





Attention:

Please make sure the rear axle is in the middle, and the axle holding out of both sides is in the same distance.


3. Rear wheel assembly

- A. Check whether the rear axle is in the middle of the car body, and make sure the axle length that extend out on both sides are same.
- B. Use the prepared sleeve tool to remove the nut and washer, then attach the rear wheel to the rear axle, insert the washer and fix the nut with sleeve tool. Assemble the wheel cover.
- C. Assemble another rear wheel in the same way.




4. Windshield assembly

Align the windshield with the corresponding openings on the car body, insert them into place.




5. Steering wheel assembly

Match two connectors of the wires from steering wheel and steering column, align the steering wheel with steering column, press two pins on steering wheel and insert them into the holes on steering column.




6. Seat assembly

Align the seat diagonally with the corresponding position on the car body, insert the hook into the corresponding position, fix with self tapping screws at the back of the seat.




7. Spoiler assembly

Insert the spoiler into the corresponding position at the rear of the car and push them into place.





8. Mirror assembly

Align the mirror with the corresponding opening on the car body, insert and push it into place.



9. Drift switch operation

Remove the screw (a) on the rear trunk, pull inward the two hooks (b) together, remove the trunk cover. There is a drift switch beside the battery.



FUSE

This car has a auto-reset fuse, if the car stops suddenly during driving, it is mainly caused by instantaneous current exceeds ,which makes the fuse to trip. Then just stop operating for about 8 seconds, and this fuse can be reset. Then turn on the power switch again. In order to avoid the fuse tripping and cutting off power supply, please pay attention to the following matters.

This product can't be overloaded, the maximum load is 60kgs.

Don't drag anything behind the product.

Don't let the water or other liquid into the batteries and other electrical components.

Don't change the circuit system and structure of the product.

SECURITY WARNING

- 1.The installation and charging of vehicle should be under adult supervision at all times.
- 2.This product is limited to the children from 37 to 95 months, 60 kg weight limit.
- 3.This product is ideal for driving on a hard flat surface.
- 4.It is strictly prohibited in the streets or the road, pot holes, and slopes.
- 5.Avoid driving in the sand or grass or uneven ground.
- 6.Children should be given full instructions on operation of the car. Improper operation can cause damage or accidents.
- 7.While children are driving, it is parents' duty to supervise at all time to avoid accidents.
- 8.Avoid driving in rains or flooded pathways. By doing so it can damage the motor, circuit and other electrical equipments.
- 9.Battery charger should be regularly inspected by parents to insure that the wires, plugs, crusts and other components are not damaged. Please stop using if any damage is found, until it is completely restored.
- 10.In order to ensure product life and safety, avoid damaging the charger, battery or electric circuit, the car must use the default configuration of a dedicated charger and power supply.
- 11.Rechargeable batteries should be removed from the toy before charging.
- 12.If the car is not used for a long time, please cut off the product power, and keep all the switch to "stop" or "off" position.
- 13.The charger provided is not a toy. It is to be kept away from children.
- 14.Strictly prohibit using the non-manufacturer provided parts.
- 15.This product is made of PP material mainly, and the safe using time is two years.


USAGE DIRECTION

1. Before using it, make sure that all the following works are done.
 - Step described in accordance with the instructions to complete the installation of the car, the battery plug-in has been connected, the power supply has been switched on.
 - Make sure that all the positions where need the screws are fixed tightly.
 - Parents or guardian should ensure that children have taken the safety measures before using.
- To reduce the risk during using, pay attention the followings.
- When driving the car ,child should sit on the car seat.
- Adult or parents should take more care and guidance during driving and can't leave away.
- Pay attention to the driving environment and driving on the hard flat surface, not the unsafe environment.
- For example:
- a.The trenches, the riverside, slope or uneven ground;
 - b.Road or other places for driving and walking;
 - c.The obstruction which is easily hitting and causing injury;
 - d.Other unsafe zones.
- To avoid accident, please use only it in daytime or bright place, avoid using under low visibility.


WARNING:

When changing the gears, the accelerator should be released and the car has completely come to stop. Electronic steering wheel is an optional function, it can be self position. Prohibit to change the gear while the car is still moving, because that can damage the wire and other transmission parts.


2. Operation (function reference diagram)




MP3 Optional




MP3 Optional



MP4 Optional



Remote control instruction



2.4G Remoter Control Instructions

For the first time using, please match the remote control with the car, this product has a memory function, battery replacement does not need to match the code once again.

- ①. Long press "code" button more than three seconds, until the first LED lights flashing.
- ②. Turn on the power on the car, the first LED light on the remote control turns on indicating the successful pairing with the car.
- ③. When the remote control is not used for a while, it will automatically enter a sleep mode, press any key to wake it up.
- ④. Key Description: " $\triangle$ " Forward, " ∇ " Reverse, " $\triangleleft$ " Left, " $\triangleright$ " Right, "S" Speed, "P" Stop.


Press the "S" key to select the speed, 1 LED indicates low speed, 2 LED indicates medium speed, 3 LED indicates high speed, the car reverse with only medium speed.

Press the "P" key, the car will stop immediately, all LED starts flashing, press this button again to release the brake function.

WARNING:

1. When operating the car, the distance between the car which kid sit in and the remote control which operated by adults should not be more than 10 meters.
2. The remote is only for adults to use, keep far away from child.
3. Before using the remote, you must read the instruction manual carefully, and operate the empty car first , only when knowing the way of operation, you can use the remote with kid in the car.
4. Please switch the gear on "P" positon before you get on the car.
5. This product should not be used on traffic road and the place with water and obstacles.
6. To Avoid damaging the circuit, please keep the remote control from wet and rainy.
7. Don't mix old and new batteries and different brands of alkaline batteries.
8. In order to avoid damaging the remote control, please take out the batteries if not use the remote control for a long time to avoid battery leakage and circuit corrosion.
9. Avoid dropping the remote control during using.
10. Install batteries with right polarity to avoid battery short circuit.
11. Charging must be done by adults. Non rechargeable batteries can't be charged.
12. Exhausted battery should be removed from the toy properly and prevent children from playing.
13. Take out the battery if not use for long time, properly handle the battery, and prevent children from playing.
14. If the remote distance is less than 3 meters, it means the power of battery is down in the remote control, it is time to change the 2 pieces of AAA alkaline batteries.


How to insert batteries: Use screwdriver to loosen the screw on the back of the remote control, open the battery cover, and install two AAA 1.5V alkaline type batteries according to the diagram (Batteries are self-provided), then close the battery cover, and fix with screw.



CHARGING WAY

- For Safety purpose ,the charging must be done by adults.
- The first time you use it, please connect two clip locks of red wires under the seat, use it only after charging 8-12 hours.
- Charging port is locate on the dashboard, please follow the instructions to charge the battery.
- If the car has slowed down, it needs to be charged by 8-12 hours, maximum 20 hours.

1. First insert the plug of the charger into the charging port. ((The car can't be operated)
2. Then insert the charger to the power socket.



WARNING:

- 1 The toy is to be assembled by an adult. In unassembled state, it contains potentially hazardous sharp points & small parts, so please keep out of baby's reach.
- 2 CHOCING HAZARD – Small parts.
- 3 Not for children under 3 yrs.
- 4 Always wear shoes.
- 5 RISK OF FIRE. Do not bypass. Replace only with circuit protection device.
- 6 Protective equipment should be worn. Not to be used in traffic.

Attention:

- Can only use the charger and battery according to manufacturers regulations.
- Do not mix old and new or different types of batteries.
- The battery terminal should not be short circuit.
- Do not open the battery or charger.
- Do not reverse the battery.
- Before charging, please check whether the charger, battery and plug are ok, if you find any broken parts, you must stop using it immediately. And do not use it until it is fully repaired.
- The battery will be little warm when being charged, it is normal. If not, it may be caused from the short circuit of charger or circuit board.
- Must use the pressing plate to fix the battery.
- Run out of battery must be handled by adults, remove the battery which has run out from toys to recycle properly and shall not be arbitrarily discard.
- If the product is going to be stored unused long time , it must be fully charged, and charge it every 3 months ,so as to make sure the battery life.
- Charger and Battery are not toys. Keep them away from children.

MAINTENANCE AND SERVICE

1. Before using, parents should check whether all parts like batteries, charger, wires, plug, outer body and other parts are in good condition, check whether the screws are loose and whether there are potential safety hazards. Any damaged parts founded should be repaired before using.
2. After using the product for a period of time, use a small amount of lubricating oil to the moving parts to prevent wear and tear of rust.
3. Keep the car away from fire and direct sunlight. Place it stably, not upside down. The car shall be stored indoors or outdoors under cover.

4. The car should be kept away from hot items, such as stoves or heaters, or the plastic parts will melt. When charging, the car should be kept away from inflammable materials to prevent it from catching fire.
5. Charge in time after use. Charging should be done by adults. If the product is going to be unused for a long time, it must be fully charged. Charge it every month so as to extend the battery lifespan.
6. A soft cloth must be used to clean the car. Do not use chemical solvents to clean the plastic parts. Do not use soap or water to clean the car. Driving in rainy or snowy weather, water can damage the motor, battery and circuit system.
7. When stopping or storing the car, please cut off the power and make sure all switches are in the 'STOP' or 'OFF' position.
8. Do not use fuses different from the specifications of this product.
9. Do not change the product structure and circuit system. Maintenance and repair work must be done under the guidance of the professional or technical personnel in place.
10. Do not use the product for other purposes. Put the battery in the right polarity.
11. Battery negative short circuit is prohibited. Non-rechargeable batteries cannot be charged.
12. Rechargeable batteries can only be charged under the supervision of the adult.
13. Do not mix old and new batteries or different types of batteries.
14. The battery running out of power should be removed from the car properly and not allowed to be played by children.
15. Disconnect the batteries completely when not in use and do not allow children to play with them.

TROUBLESHOOTING

Car does not move or power on	If "power" switch is in OFF position
	If the fuse is not functioning properly
	If the battery is not connected, check the red and black wires.
	If the charger is plugged in, car will not power on. Unplug charger.
	If the pedal switch is not functioning properly
	If the wheels stuck and cannot move
Car moves slowly	If the battery is not fully charged. Need to be charged in time
	If there is an issue with the wheels
	If rider weight exceeds specifications
Battery does not charge	If the charger is malfunctioning
	If the battery lost its capacity
	If the charger and battery connection are charged

PINGHU SHUANGXI BABY CARRIER MANUFACTURE CO.,LTD.
PINGHU BABY CARRIER INDUSTRY CITY, ZHEJIANG, CHINA

