

MERCEDES-BENZ 300S CHILDREN BATTERY CAR SPECIFICATIONS



Original License Counterfeit Investigated

Execute standard: GB6675 GB19865

Welcome to use our children ride-on cars. To ensure you can use our products correctly, please read through this manual before use. The toy must be assembled by adult .

Parts List



- | | |
|---------------------|-------------------------|
| 1.Car body *1 | 7. Car seat*1 |
| 2.Steering Wheel *1 | 8. Remote control*1 |
| 3.Front wheels*2 | 9. Charger*1 |
| 4. Rear wheels*2 | 10. Gasket*7 |
| 5. Wheel covers*4 | 11. Pin*5 |
| 6.Windshield*1 | 12. Screw*1 |
| | 13.Mercedes-benz logo*1 |

Assemble steps



I Wheels Installation

1. Install left and right front wheels: first put one gasket on front axle, then install the wheel, put another gasket outside the wheel and use cotter pin to lock it. (as shown above.)

2. Install driving wheel: first install the motor and connect it, put the wheel on, then one gasket and a cotter pin to lock it.

3. Install wheel cover: buckle it on the wheel, press it till a sound “ka” for fixation.



II Windshield Shelf Installation:

Press down the windshield shelf into the relative gaps on the vehicle.

Assemble steps



III. Steering Wheel Installation

First remove the screws and nuts, then connect the wires, insert the steering wheel in the steering rod. Align the side screw holes, lock it with the screws and nuts,



IV.Seat Installation

First connect the wires correctly, then place the seat in the position as picture shown then fix it to car body by 1 screw.

Method of use



Warning!

* For the remote control function, please take reference to the instruction in the remote control box.

* To avoid gearbox and motor damage, ensure the vehicle has completely stopped when shift gears.

* Running function: Set in the switch in forward, the vehicle will move forward when you stepping on "foot switch". Set it in backward state, the vehicle will run backward. Set the switch in the middle, the vehicle can not move. (If the car has remote control function, you can also control the car with the controller.)

charging

Charging must be done by adult

Warning!

To avoid fires and electric shock:

---Only allowed to use the battery and charger prescribed by the manufacturer.

Prohibit to use the other brand.

---Do not put the battery and charger in other products.

---It is not allowed to change the line structure privately.

---Do not link positive terminal and negative terminal by any conductor

---Please keep the battery dry, far away from any liquid

---When charging, do not smoking nearby, any flames may cause explosion.

---Please charge the vehicle in well ventilated, dry area.

Charging precautions

- *Batteries can not be reversed.
 - *battery type: colsed dry battery.
 - *Please check the charger,battery and plug before charging, if any damage found, stop using unless repair intact.
 - *It's normal for battery heating in charging process,if the temperature is too high, please check either the current flow is too strong or battery internal short-circuit
 - *To avoid likely damage caused by battery to child,must fix the battery with platen
 - *if the vehicle unused for long time, it must be fully charged, and charge once each month to ensure the battery life.
 - *Batteries are only to be charged by adults or children at least 8 years old.
 - *the batteries of the remote controller are non-rechargeable, do not charge them.
- Batteries should be installed with the correct polarity. Do not mixed different types of batteries or new and used batteries. Exhausted batteries must be removed from the vehicle.

When charging,turn off the power switch.

Before first use,recommend to charge 4 to 6 hours but not more than 10 hours

When the vehicle speed slows down obviously, indicating the battery is low,please charge.

After use,please charge 4 to 8 hours,not exceeding 20 hours.charger




TROUBLESHOOTING

■ Problem: The car will not move

Answer 1: Please make sure the charger has been removed from the car charging point

Answer 2: The battery is low on charge. Please charge for 6–8 hours but not exceeding 10 hours

Charge at least once a month to keep the cells active.



To avoid fuse cut off the power:

1. Max:30kgs, overload is forbidden
2. Do not drag any item behind this product.
3. Do not allow water or other liquids dip the electrical parts.
4. Do not change the line system by yourself.

Answer 3: driving wheel nuts loose

If the nut is not locked tightly, the motor can not work.. Please lock the nut tightly with wrench.

Answer 4: the battery plug-ins or wires loose

Make sure the battery plug-ins have connected correctly, wire without loosening

Answer 5: battery is broken

Please contact the agent or manufacturer

Answer 6: car body wiring has been damaged

Please contact the agent or manufacturer

Answer 7: the motor is damaged

Please contact the agent or manufacturer

Problem: unable to charge

Answer 1: the battery plug-ins loose

Make sure the battery terminals have connected with the wires tightly

Answer 2: the charger is not inserted in place

Make sure the charger is plugged into the power outlet properly {ensure the power outlet switch turn on}

Answer 3: the charger can not work normally

If the charger no warmed, please contact the agent or manufacturer

Problem: vehicle run for a short time

Answer 1:the battery is not fully charged.

The charging time is not enough,please charge in time after each use.

Recommend to charge 8 to 12 hours but not exceeding 20 hours.

Answer 2:battery aging

Battery service life:1-3 years,otherwise,change a new one.

Problem: charger makes a buzzing sound while charging

This is normal.

Problem: charger heating phenomenon

This is normal.if the battery temperature is too high,please check either the current flow is too strong or battery internal short-circuit

Note on Safety

1.This vehicle is not suitable for children under 36 months. Please use this vehicle under the supervision of adults.

2. Please keep this vehicle far from pool, highway, slopes or other dangerous places.

3. To avoid gearbox and motor damage, ensure the vehicle has completely stopped when shift gears.

4. Before using, parents should check the main parts:battery,charger,wires,plugs,shell and other parts for not damaging;screw loose whether;if there is potential security risks.Any damage found,stop using until well repaired.

5. To avoid rust , lubricate the iron parts with lubricating oil after using for some time.

6. The vehicle should be kept away from fire and long-term light side-up for shortage,upside down

7. Do not use the fuse not matching the product.

8. Do not change the wire system by yourself,the repair work must be carried out under the guidance of professionals and technical staff.

Remote control priority function



For the remote control function, please take reference to the instruction in the remote control box.

Suitable age: For children between 37 months to 96 months old only.
(Please use this vehicle under the supervision of adults)

- 1.The maximum loading capacity of this vehicle is 30KGS, and can take only one child.
- 2.This Vehicle is suitable for children aged 37-96 months.
- 3.Please use this vehicle under the guidance and supervision of adult.
Prohibited to use this vehicle on the road, slopes, highway and other dangerous places. Also prohibited to use this vehicle near swimming pool or any other water area. When driving, children should keep shoes on and wear helmet, and should be seating in the seat and fasten the seat belt.
- 4.This vehicle can only use the batteries and chargers that approved by the manufacturer.
- 5.Please keep the vehicle far away from fire.
- 6.Battery Size: 152(L)*65(W)*96(H) MM
Battery Specifications: 12V7A

Original License Counterfeit Investigated

Execute standard: GB6675 GB19865